	Fitment Instructions	Model: SUZUKI Grand Vitara		Underbody Protection	Plate	Part number: IUF	P011T
	Transmission		Years: 2005-		Engine type: all (1.6,1.9, 2.0, 2.4, 3.2 V6)		

APPLICATION:

Protection of engine bay and transmission elements from damage. Protection of engine bay and transmission elements from dust and water.

INSTALLATION:

This protection plate has been designed for installation to the intended application only. It should be mounted according to these installation instructions by an experienced Ironman 4x4 dealer or certified fitter. The plate is fixed to original vehicle mountings located on the vehicle's body load-bearing elements. Upon successful installation the plate should not interfere with any other parts or components.

INSTALLATION MANUAL:

- 1. The plate is to be installed after mounting the plate for engine bay.
- 2. Install the rear drop bracket, place one end under the fuel pump OE bolt, fix the other end to the vehicle with an M8x20bolt.
- 3. Mount threaded inserts to the transmission's beam.
- 4. Install the front of plate "A" to the engine bay plate, and the rear to the transmission beam.
- 5. Install the front of plate "B" to the rear of part "A" incorporating the transmission beam and threaded inserts.
- 6. Tighten all screw joints.

WARRANTY:

Warranty period - 12 Months


WARRANTY TERMS:

The plate should only be installed on a vehicle with undamaged body and load-bearing elements, vehicles which have been involved in a significant collision may prevent successful installation.

Ironman 4x4 does not bear liability for any damages caused to the vehicle, or injury to persons in case of installation or product failure. Ironman 4x4 has a right to introduce changes into the skid plate construction.

10	ΝU	V.F.	2
5	Ŀ	2	E
"	E,	œ	17
1	¥.	2	1

The Quality Management System at production has been audited by Bureau Veritas Certification and conforms to requirements of the ISO 9001:2008 standard.



LIST OF PARTS

NO.	NAME		QTY.	NO.	N	NAME		QTY.
1	Rear drop bracket		1	5	В	olt M 8x20		1
2	Threaded insert		2	6	Bolt M 10x20			4
3	Washer 8		1	7	Bolt M 10x60			2
4	Washer 10		6	8	8			
	Thread M6x ²		1.0	M8x1.25		M10x1.5 M12		x1.75
Tigh	Tightening torque 9.8 M		Nm	24.0 Nm		47.0 Nm 81.		0 Nm

www.ironman4x4.com

IRONMAN 4X4

MELBOURNE SHOWROOM Cnr Centre & Westall Roads, Clayton, Victoria 3168 Telephone +61 3 9532 1111

IRONMAN 4X4 BRISBANE SHOWROOM 1 Hinkler Court Brendale, QLD, 4500 Telephone (07) 3482 9500

IRONMAN 4X4 PERTH SHOWROOM Unit 9/511 Abernethy Road Kewdale, WA, 6105 Telephone (08) 6254 4444